


National Baling Press Manual



National Baler Manual

Rating: Not Rated Yet

Price

Sales price \$35.00

Sales price without tax \$35.00

Tax amount

[Ask a question about this product](#)

Description

50 Page Downloadable Manual for National Balers, Includes Operation, Electrical Schematic, Hydraulic Schematic, Safety. Covers Models HY-36 HY36, HY-45 HY45, HY-50 HY50, HY-54 HY54, HY-60 HY60, HY-72 HY72

This is a copy of the original factory manual for National Baling Press. Includes Operation Instructions, Electrical Schematic, Hydraulic Schematic, Safety. Covers Models HY-36 HY36, HY-45 HY45, HY-50 HY50, HY-54 HY54, HY-60 HY60, HY-72 HY72

50 Page Obsolete Manual.

\$35 for Downloadable PDF file upon checkout.

This is very important to Read!!!

*****Important Please Read*****

This is a downloadable PDF of this manual. Once you

purchase the manual, you will be emailed an invoice which includes a "Download Now" Clickable link.

Paragraph	Title	Page
INDEX OF CONTENTS		
SECTION I - OPERATOR AND SAFETY INFORMATION		
I-1	Introduction and Safety Information	1-1
I-2	Safety Symbols and Signal Words	1-2
I-3	Operator Responsibilities	1-3
I-4	Safe Operation Practices	1-4
I-5	Emergency Procedures	1-5
SECTION II - BALE OPERATION AND MAINTENANCE		
II-1	General	2-1
II-2	Pre-Operation Checklist	2-2
II-3	Pre-Start Checks	2-3
II-4	Starting the Engine	2-4
II-5	Operating the Baler	2-5
II-6	Stopping the Engine	2-6
II-7	Post-Operation Checks	2-7
II-8	Storage and Winterization	2-8
II-9	Troubleshooting	2-9
II-10	Maintenance	2-10
II-11	Lubrication	2-11
II-12	Fluids and Additives	2-12
II-13	Adjusting the Bale Density	2-13
II-14	Adjusting the Bale Length	2-14
II-15	Adjusting the Bale Width	2-15
II-16	Adjusting the Bale Moisture	2-16
II-17	Adjusting the Bale Quality	2-17
II-18	Adjusting the Bale Uniformity	2-18
II-19	Adjusting the Bale Consistency	2-19
II-20	Adjusting the Bale Stability	2-20
II-21	Adjusting the Bale Appearance	2-21
II-22	Adjusting the Bale Performance	2-22

Paragraph	Title	Page
INDEX OF CONTENTS (continued)		
SECTION III - SAFETY INFORMATION		
III-1	Safety Symbols and Signal Words	3-1
III-2	Operator Responsibilities	3-2
III-3	Safe Operation Practices	3-3
III-4	Emergency Procedures	3-4
SECTION IV - OPERATOR MAINTENANCE		
IV-1	General	4-1
IV-2	Pre-Operation Checklist	4-2
IV-3	Pre-Start Checks	4-3
IV-4	Starting the Engine	4-4
IV-5	Operating the Baler	4-5
IV-6	Stopping the Engine	4-6
IV-7	Post-Operation Checks	4-7
IV-8	Storage and Winterization	4-8
IV-9	Troubleshooting	4-9
IV-10	Maintenance	4-10
IV-11	Lubrication	4-11
IV-12	Fluids and Additives	4-12
IV-13	Adjusting the Bale Density	4-13
IV-14	Adjusting the Bale Length	4-14
IV-15	Adjusting the Bale Width	4-15
IV-16	Adjusting the Bale Moisture	4-16
IV-17	Adjusting the Bale Quality	4-17
IV-18	Adjusting the Bale Uniformity	4-18
IV-19	Adjusting the Bale Consistency	4-19
IV-20	Adjusting the Bale Stability	4-20
IV-21	Adjusting the Bale Appearance	4-21
IV-22	Adjusting the Bale Performance	4-22

Paragraph	Title	Page
INDEX OF CONTENTS (continued)		
SECTION V - OPERATOR MAINTENANCE		
V-1	General	5-1
V-2	Pre-Operation Checklist	5-2
V-3	Pre-Start Checks	5-3
V-4	Starting the Engine	5-4
V-5	Operating the Baler	5-5
V-6	Stopping the Engine	5-6
V-7	Post-Operation Checks	5-7
V-8	Storage and Winterization	5-8
V-9	Troubleshooting	5-9
V-10	Maintenance	5-10
V-11	Lubrication	5-11
V-12	Fluids and Additives	5-12
V-13	Adjusting the Bale Density	5-13
V-14	Adjusting the Bale Length	5-14
V-15	Adjusting the Bale Width	5-15
V-16	Adjusting the Bale Moisture	5-16
V-17	Adjusting the Bale Quality	5-17
V-18	Adjusting the Bale Uniformity	5-18
V-19	Adjusting the Bale Consistency	5-19
V-20	Adjusting the Bale Stability	5-20
V-21	Adjusting the Bale Appearance	5-21
V-22	Adjusting the Bale Performance	5-22

Figure	Title	Page
LIST OF ILLUSTRATIONS		
F-1	Operator Positioning	6-1
F-2	Pre-Start Checklist	6-2
F-3	Starting the Engine	6-3
F-4	Operating the Baler	6-4
F-5	Stopping the Engine	6-5
F-6	Post-Operation Checks	6-6
F-7	Storage and Winterization	6-7
F-8	Troubleshooting	6-8
F-9	Maintenance	6-9
F-10	Lubrication	6-10
F-11	Fluids and Additives	6-11
F-12	Adjusting the Bale Density	6-12
F-13	Adjusting the Bale Length	6-13
F-14	Adjusting the Bale Width	6-14
F-15	Adjusting the Bale Moisture	6-15
F-16	Adjusting the Bale Quality	6-16
F-17	Adjusting the Bale Uniformity	6-17
F-18	Adjusting the Bale Consistency	6-18
F-19	Adjusting the Bale Stability	6-19
F-20	Adjusting the Bale Appearance	6-20
F-21	Adjusting the Bale Performance	6-21